

# DSP HW2-2

## Speech Analysis

# Outline

1. Introduction
2. Praat
3. Homework Problems
4. Submission Requirements

# Introduction

- Analyze speech signal from spectrogram
- Try to distinguish different initials(聲母) and finals(韻母) on spectrogram.
- Right-Context-Dependent Initial Final (RCDIF)  
 $t_i$  for 去 followed by finals starting with —  
ex 1 : 去— =  $t_i i$   
ex 2 : 去Y =  $t_a a$

# Introduction

- classification of consonants

Plosive/Stop	爆破音/塞音	ㄅㄆㄈㄉㄊㄋ
Fricative	擦音	ㄏㄏㄏㄏ
Affricate	塞擦音	ㄎㄏㄕㄔㄕㄔ
Nasal	鼻音	ㄇㄻ


- classification of vowels

Monophthong	單母音	ㄧㄨㄚㄛㄞㄢㄤㄦㄩㄮ
Diphthong	雙母音	ㄞㄟㄠㄡ

# Introduction

Some useful information about labeling.

- “*sil*” for silence.
- “*sp*” for short pause.
- fricative/affricate initials do not contain voicing parts.
- plosive initials contain closure or aspiration period.



# Some files you need

1. Phonetic class table (聲韻母表):

[http://speech.ee.ntu.edu.tw/homework/DSP\\_HW2-2/phonetic\\_class.pdf](http://speech.ee.ntu.edu.tw/homework/DSP_HW2-2/phonetic_class.pdf)

2. Syllable table (標註模式):

[http://speech.ee.ntu.edu.tw/homework/DSP\\_HW2-2/syllable.txt](http://speech.ee.ntu.edu.tw/homework/DSP_HW2-2/syllable.txt)

3. Audio data & FAQ:

[http://speech.ee.ntu.edu.tw/homework/DSP\\_HW2-2/](http://speech.ee.ntu.edu.tw/homework/DSP_HW2-2/)


# Praat

1. Download


<http://www.fon.hum.uva.nl/praat/>

2. How to read a wave file
3. How to use it
4. How to label


# Praat




# Praat - Read from file (.wav file)




# Praat - click *View & Edit*




# Praat - Time and Frequency Domain




# Praat - Pitch 音高 ( *pitch* -> *Show pitch* )



# Praat - Intensity 音量( *Intensity* ->*Show Intensity* )



# Praat - Formant 共鳴 (*Formant* -> *Show formants*)



# Praat - Reminder


**1. *Intensity*:** power of all frequency components

Two acoustic signals may have the same intensity but different frequency components.

**2. *Formant*:** acoustic resonance, measured by the peak in the frequency spectrum


You should not trust the formant detection output for unvoiced initials.

# Praat - Label a wave file (*Annotate* -> *To TextGrid*)




## Praat - Label a wave file

- Create one interval tier named RCDIF
- No point tiers




# Praat - Label a wave file

- With **BOTH** objects selected
- click ***View & Edit***




# Praat - Label a wave file



## Praat - Label a wave file


- Click on spectrogram for your boundary
- Add the boundary by clicking the small circle  
Remove by choosing “Boundary/Remove”
- Drag your boundaries to be more accurate
- Click between your boundary and type in your label  
(according to the “Syllable table”)  
Listen to your label by clicking the number (interval time) below it

# Praat - After labeling



## Praat - Save your Label file

- Save your TextGrid object as short text file  
File should be “.TextGrid” not “.Collection”





## Report - Part 1 (20%)

- Choose your wave files from directories according to your student ID (<https://goo.gl/ero6Ka>).
- You must submit at least 5 fully labeled TextGrid files **(along with their wave files)**.
- These 5 files should contain the initial/final labels you use in part 2.


## Report - Part 2 (30%)

- Choose at least 2 initials from the 4 classes (Plosive, Fricative, Affricate, Nasal)
- For each of these 8 initials, create a table that contains at least 2 screenshots of its label.
- Please show intensity and formant.

## Part 2 - example : Plosive b (ບ)

Phonetic Class			
Plosive	b(ບ)	 b_e 0.092705	 b_e 0.049

## Part 2 - example : Plosive p (ㄅ)

Phonetic Class		
Plosive	p(ㄅ)	

## Part 2 - Useful tips

- Zoom in and Zoom out.
- show all or selection part in Praat by clicking the buttons on the lower-left corner of spectrograms.
- In your chosen directory.  
“NTU\_XXXXX\_phn2file” lists all files containing each phone  
“NTU\_XXXXX\_file2phn” lists all phones contained in each file

## Report - Part 3 (50%)


1. (20%) What are the consistencies of the spectrogram in each phonetic class? (Plosive, Fricative, Affricate, Nasal)
2. (10%) Is the boundary between neighboring initial and final clear? What is the benefit of using “right-context dependent” initial model (ex: sh\_a) instead of pure initial model (ex: sh) to model initials?

## Report - Part 3 (50%)

3. (10%) What are the differences when pronouncing  
ㄉ & ㄉ? How can you tell the differences in  
spectrogram for ㄉ & ㄉ? (You may also want to  
compare ㄉ & ㄉ, ㄉ & ㄉ respectively)
4. (10%) Take a look at the spectrogram of finals. Is there  
any simple rules to discriminate initials from finals  
provided only spectrogram?

## Report - Bonus (10%)

- The following is a speech analysis plot for a Chinese word composed of 4 characters. Each character is composed of an initial and a final.
- Guess what the word is and describe your reasoning.  
(Score: reasoning 8%, correct answer 2%)
- If you cannot figure out the word, you can guess the phonetic class or initial/finals.  
For example, your answer can be “l\_i, i, sic\_a, au” or “plosive, diphthong, plosive, monophthong”.



# Submission Requirements

1. 5 TextGrid files (each along with its wave file).  
the “.TextGrid” & “.wav” filenames should be the same.
  
2. 1 report (in PDF format).  
the filename should be hw2-2\_bXXXXXXXXXX.pdf (your student ID).

# Submission Requirements

3. Put those **11 files in a folder**, compress the folder to 1 zip file and upload it to **ceiba**.

- Folder name should be hw2-2\_bXXXXXXXXX (e.g. hw2-2\_b02901000)
- .zip or .tar.gz only
- 20% of the final score will be taken off for wrong format

## Homework 2

- You can submit either
  - HW 2-1 (HMM Training and Testing)
  - HW 2-2 (Speech Analysis)
- You can also submit both
- The higher grade of the two will count as your final score for HW2
- **Deadline: To be discussed**

**10%** of the final score will be taken off for each day of late submission